







































Original		Substitut		Original		Substitut	
	Power		Power		Channel -		Ch -
	Quick Select 1		1		Tune +		>>
	Quick Select 2		2		Tune -		<<
	Quick Select 3		3		Mute		Mute
	Quick Select 4		4		CH Level		3D
	CBL/SAT		5		Sleep		Sleep
	DVD		6		Dimmer		Text
	Blu-ray		7		Search		TV/R
	Game		8		Info		Info
	AUX		9		Audio		Dual
	Tv Audio		Guide		Back		Back
	Tuner		0		Setup		Menu
	Memory		Pre Ch		Vol+		Vol +
	Band		List		Vol-		Vol -
	Shift		AV		Up		Up
	Mode		Exit		Down		Down
	Channel +		Ch +		Right		Right





Original	Substitut	Original	Substitut
	Left		Left
	Enter		Ok
	Night		Options
	Restorer		Eject
	Tone		D. Menu
	< Surround		Yellow
	Surround >		Blue
	Audio Delay +		>>
	Audio Delay -		<<

