





































































Original	Substitut	Original	Substitut
	Power		Power
	Quick OSD		Media
	FL Select		Smart
	Open/Close		Eject
	Advanced		TV/R
	Picture Mode		Format
	Repeat		Text
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Original	Substitut	Original	Substitut
	+10		Guide
	Cancel		Exit
	Play Speed		Red
	Dialogue		Green
	Manual Skip		Yellow
	Quick Replay		List
	I<< Skip		I<<
	Skip >>I		>>I
	<< Slow/Search		<<
	Slow/Search >>		>>
	Stop		Stop
	Pause		Pause
	Play		Play
	Top Menu		Shift + Menu
	Menu		Menu
	Functions		D. Menu
	Return		Back



