



































Original	Substitut
	 Power
	 Mute
	 Info
	 Options
	 Shift + Format
	 Shift + Dual
	 AV
	 Guide
	 >>
	 <<
	 Pre Ch
	 Menu
	 Format
	 Dual
	 Exit
	 Vol -
	 Vol +

Original	Substitut
	 Up
	 Left
	 Ok
	 Right
	 Down
	 Ch -
	 Ch +
	 Red
	 Shift + Left
	 Green
	 Shift + Down
	 Yellow
	 Shift + Up
	 Blue
	 Shift + Right
	 1
	 2





Original	Substitut	Original	Substitut
	 Power		 9
	 AV		 0
	 Exit		 Guide
	 Menu		 Up
	 Dual		 Right
	 Media		 Ok
	 Options		 Left
	 Text		 Down
	 TV/R		 Subt
	 1		 Pause
	 2		 Rec
	 3		 <<
	 6		 Play
	 5		 >>
	 4		 Shift + Media
	 7		 Shift + Dual
	 8		 Shift + 6

