



Original	Substitut	Original	Substitut
	Power		Power
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Play		Play / Slow
	>>		>> / Tune+
	<<		<< / Tune-
	Guide		Guide / EPG / -/--
	3D	+	Shift + 3
	Smart Tv		Smart / List
	Home		Menu / Home
	Ambilight		Display / Media
	[<>]		Picture / Format
	TV		TV/Radio /
	OK		OK
	Up		Up
	Down		Down

Original	Substitut	Original	Substitut
	Right		Right
	Left		Left
	[i]/Info		Info / Angle
	Exit		Exit / Cancel / Clear
	Back		Back / Return
	List	+	Shift + Smart / List
	III/Options		Setup / OPT /
	Mute		Mute / Dimmer
	Vol+		Vol+
	Vol-		Vol-
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	1		1



