












Original	Substitut	Original	Substitut
	POWER		Power
	SOURCE		AV
	EXIT		Exit
	MENU		Menu
	AUDIO		Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	MUTE		Mute
	PIC MODE		Shift + Format
	TEXT		Text
	TV / RADIO		TV/R
	OK		Ok
	UP / CH+		Up
	DOWN / CH-		Down
	RIGHT		Right
	LEFT		Left
	PAGE UP		Ch +
	PAGE DOWN		Ch -
	VOL+		Vol +
	VOL-		Vol -
	SLEEP		Sleep
	SUB.		Subt
	RECALL		Back
	RED		Red
	GREEN		Green





Original		Substitut		Original		Substitut	
	YELLOW		Yellow				
	BLUE		Blue				
	STOP		Stop				
	PAUSE		Pause				
	REC		Rec				
	REW		<<				
	PLAY		Play				
	FWD		>>				
	SAT		Smart				
	EPG		Guide				
	HELP		D. Menu				
	V. FORMAT		Format				
	INFO		Info				
	T / S		List				
	POS.		Media				

