



























Original	Substitut
	Power
	Tv/Text
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	AV/Input Select
	-/--
	Tracking/V-Lock+
	Tracking/V-Lock-
	Vol+

Original	Substitut
	Vol-
	Search
	Show View
	OSD/Display
	Replay
	Direct Tv Rec
	I<< Index
	Index >>I
	Rec
	Pause/Step
	Menu
	OK
	Play/Up
	Stop/Down
	>>/Right
	<</Left
	SP/LP








Original		Substitut		Original		Substitut	
	Timer Rec		3D		Exit		Exit
	Prog/Check		Sleep				
	Reset		Back				
	Audio		Dual				
	VPS/PDC		Subt				
	AV Link		Media				
	TV Aspect		Eject				
	Still Album		List				
	Up		Up				
	Down		Down				
	Date+		Right				
	Date-		Left				
	On+		Red				
	On-		Green				
	Off+		Yellow				
	Off-		Blue				
	Cancel		D. Menu				





Original	Substitut
	Power
	TV/Text
	CH+
	CH-
	Vol+
	Vol-
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	-/--

Original	Substitut
	AV Input Select
	Red
	Green
	Yellow
	Blue

