


Original	Substitut
	Mute / Dimmer
	Vol+
	Right
	CH+ / Page+
>< button icon"/>	Fav / Marker / PC
	Vol-
	Left
	CH- / Page-
	Back / Return
	4
	5
	2
	3
	0
	1
	8
	9

Original	Substitut
	6
	7
	AV / Input / RDS
	Zoom / Size
	TV/Radio /
	Audio / Lang I/II
	Subtitle / EQ
	Guide / EPG / -/-
	>> / Tune+
	Shift + >> /
	Up
	>>  / Preset+
	<< / Tune-
	Shift + << /
	Down
	<< / Preset-
	Red / Netflix / Search







Original	Substitut	Original	Substitut
	Mute		Mute / Dimmer
	Vol+		Vol+
	Color+		Right
	P/CH+		CH+ / Page+
	><		Fav / Marker / PC
	Vol-		Vol-
	Color-		Left
	P/CH-		CH- / Page-
	Return		Back / Return
	4		4
	5		5
	2		2
	3		3
	0/AV		0
	1		1
	8		8
	9		9
	6		6
	7		7
	Input/[=]		AV / Input / RDS
	CH/[ ]		Zoom / Size
	P/[ ]		TV/Radio /
	P1/[?]		Audio / Lang I/II
	P2/[+]		Subtitle / EQ
	100		Guide / EPG / -/-
	Ant+		>> / Tune+
	Tune+		Shift + >> /
	*+		Up
	Contrast+		>>  / Preset+
	Ant-		<< / Tune-
	Tune-		Shift + << /
	*-		Down
	Contrast-		<< / Preset-
	Ant 1-2		Red / Netflix / Search



