







































































Original	Substitut
 Power	 Power
 Sources	 AV / Input / RDS
 Text	 Text / Goto
 T.Opt	 Setup / OPT /
 AD	 Audio / Lang I/II
 *	 D.Menu / Top
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Guide	 Guide / EPG / -/--
 0	 0

Original	Substitut
 ...	 Fav / Marker / PC
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Search	 Sleep / Timer
 CH-	 CH- / Page-
 TV	 TV/Radio /
 Netflix	 Shift + Red / Netflix /
 Home	 Menu / Home
 Prime video	 Shift + Blue / Prime
 Disney+	 Display / Media
 Up	 Up
 Rakuten Tv	 Shift + Yellow / YouTube /
 Left	 Left
 OK	 OK
 Right	 Right



