






































Original	Substitut	Original	Substitut
	Power		Power
	Open/Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	10+		Guide
	Video Out		AV
	<<		<<
	>>		>>
	Pause		Pause

Original	Substitut	Original	Substitut
	Stop		Stop
	Play		Play
	I<<		I<<
	>>I		>>I
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu DVD		Menu
	Setup		Options
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Language		Dual
	Angle		TV/R
	Subtitle		Subt



