























































Original	Substitut		
	View DVD		Smart
	View VCR		Media
	TV / VCR		TV/R
	Input SEL.		AV
	Standby / On		Power
	Open / Close		Eject
	Info		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Original	Substitut		
	Timer		Shift + AV
	F.ADV / Step		Pre Ch
	I<<		I<<
	Rec		Rec
	Speed		Sleep
	>>I		>>I
	<<		<<
	Stop		Stop
	Play		Play
	Pause		Pause
	>>		>>
	TRK +		Vol +
	TRK -		Vol -
	Audio		Dual
	Prog +		Ch +
	Prog -		Ch -
	Menu		Menu





Original	Substitut
Return	Back
Up	Up
Right	Right
Down	Down
Left	Left
OK	Ok
Disc Menu	D. Menu
Clear	Exit
Zoom	Shift + Eject
EZ View	Options
Subtitle	Subt
Angle / IPC	Format
Mode / Repeat	Text
Mark / Search	Shift + TV/R

Original	Substitut

