






































































Original	Substitut	Original	Substitut
	Power		Power
	Sleep		Sleep / Timer
	Input TV		AV / Input / RDS
	Power TV		Shift + Power
	Program		TV/Radio /
	1		1
	2		2
	Repeat		Green / APP / Repeat
	Function+		CH+ / Page+
	3		3
	EQ		Shift + Subtitle / EQ
	4		4
	DSGX		Sound / Title
	5		5
	Function-		CH- / Page-
	6		6
	Zoom		Zoom / Size

Original	Substitut	Original	Substitut
	7		7
	Dimmer		Shift + Mute / Dimmer
	8		8
	Time		Shift + Sleep / Timer
	9		9
	0		0
	0/Subtitle		Subtitle / EQ
	Audio		Audio / Lang I/II
	Angle		Info / Angle
	DVD Top Menu		Menu / Home
	DVD Menu		D.Menu / Top
	Setup		Setup / OPT /
	Display		Display / Media
	Muting		Mute / Dimmer
	Vol+		Vol+
	Vol-		Vol-
	Up		Up



