









































Original	Substitut
 Open / Close	 Eject / Surround
 Input Select	 AV / Input / RDS
 HDMI	 Shift + 0
 Power	 Power
 1	 1
 2	 2
 3	 3
 Prog +	 CH+ / Page+
 4	 4
 5	 5
 6	 6
 Prog -	 CH- / Page-
 7	 7
 8	 8
 9	 9
 Time Slip	 Shift + >> /
 Sat. Link	 Smart / List

Original	Substitut
 0	 0
 Clear	 Exit / Cancel / Clear
 Info	 Info / Angle
 Text	 Text / Goto
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Guide	 Guide / EPG / -/-
 Top Menu	 Menu / Home
 Disc Menu	 D.Menu / Top
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Display	 Display / Media
 Down	 Down
 Return / Back	 Back / Return
 Red	 Red / Netflix / Search





Original	Substitut
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Shift + Red / Netflix /
	<< / Tune-
	Play / Slow
	>> / Tune+
	l<< / Preset-
	Stop / Hold
	>>l / Preset+
	Pause / Step / Freeze
	Shift + 4
	Shift + 2
	Shift + >>l / Preset+
	Sound / Title
	Rec / Rec Mode
	Shift + Rec / Rec Mode

Original	Substitut
	Setup / OPT /
	Sleep / Timer
	TV/Radio /
	Shift + Play /

