







































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV/Source		AV
	-/--		Shift + Guide
	[i]/Info		Info
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	[≡i]/Guide		Guide
	Menu		Menu
	Red		Red
	Exit		Exit
	Green		Green
	I-II		Dual
	Swap/P<P		Pre Ch
	Yellow		Yellow
	TV/DTV		TV/R
	<<		I<<





	Original	Replacement	Original	Replacement
	Blue	 D		
	<<			
	Play	 PLAY MODE		
	>>			
	>>>			
	Stop			
	Pause/[+]			
	Rec/PP	 REC MODE		
	[≡+]	 SETTINGS OPT		
	[≡x]	 AD SUBT		
	[.≡]	 APP MEDIA		
	[≡]	 REPEAT TEXT		
	[≡?]	 PICTURE FORMAT		
	[≡o]	 ECO 3D		

