












Original	Replacement	Original	Replacement
 Power	 Power	 Channel -	 Ch -
 Quick Select 1	 1	 Tune +	 >>
 Quick Select 2	 2	 Tune -	 <<
 Quick Select 3	 3	 Mute	 Mute
 Quick Select 4	 4	 CH Level	 3D
 CBL/SAT	 5	 Sleep	 Sleep
 DVD	 6	 Dimmer	 Text
 Blu-ray	 7	 Search	 TV/R
 Game	 8	 Info	 Info
 AUX	 9	 Audio	 Dual
 Tv Audio	 Guide	 Back	 Back
 Tuner	 0	 Setup	 Menu
 Memory	 Pre Ch	 Vol+	 Vol +
 Band	 List	 Vol-	 Vol -
 Shift	 AV	 Up	 Up
 Mode	 Exit	 Down	 Down
 Channel +	 Ch +	 Right	 Right





Original	Replacement	Original	Replacement
