







































































Original	Replacement
	 Mute / Dimmer
	 Power
	 Display / Media
	 Guide / EPG / -/--
	 Sleep / Timer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Zoom / Size
	 0
	 AV / Input / RDS

Original	Replacement
	 Setup / OPT /
	 Picture / Format
	 TV/Radio /
	 Smart / List
	 Rec / Rec Mode
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Red / Netflix / Search
	 Up
	 Blue / Prime Video / Random
	 Left
	 OK
	 Right
	 Exit / Cancel / Clear
	 Info / Angle
	 Down
	 << / Tune-









































































Original	Replacement	Original	Replacement
	Stop		Stop / Hold
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	>>		>> / Tune+
	Prog -		CH- / Page-
	Prog +		CH+ / Page+
	Volume -		Vol-
	Volume +		Vol+
	TXT		Text / Goto
	Still	+	Shift + Pause / Step /
	Sound		Sound / Title
	PIP		D.Menu / Top
	Menu		Menu / Home
	HDMI	+	Shift + 0





Original	Replacement
	 Mute / Dimmer
	 Power
	 Fav / Marker / PC
	 Smart / List
	 Sleep / Timer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Zoom / Size
	 0
	 AV / Input / RDS

Original	Replacement
	 Setup / OPT /
	 Display / Media
	 TV/Radio /
	 D.Menu / Top
	 Rec / Rec Mode
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Red / Netflix / Search
	 Up
	 Blue / Prime Video / Random
	 Left
	 OK
	 Right
	 Exit / Cancel / Clear
	 Info / Angle
	 Down
	 << / Tune-









































































Original	Replacement
	 Stop / Hold
	 Play / Slow
	 >> / Tune+
	 CH- / Page-
	 CH+ / Page+
	 Vol-
	 Vol+
	 Text / Goto
	 Pause / Step / Freeze
	 Sound / Title
	 Picture / Format
	 Menu / Home
	 Shift + 0

Original	Replacement



































Original	Replacement
	 Mute / Dimmer
	 Power
	 Display / Media
	 Guide / EPG / -/--
	 Sleep / Timer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Zoom / Size
	 0
	 AV / Input / RDS

Original	Replacement
	 Setup / OPT /
	 Picture / Format
	 TV/Radio /
	 Smart / List
	 Rec / Rec Mode
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Red / Netflix / Search
	 Up
	 Blue / Prime Video / Random
	 Left
	 OK
	 Right
	 Exit / Cancel / Clear
	 Info / Angle
	 Down
	 << / Tune-





Original	Replacement
	 Stop / Hold
	 Play / Slow
	 Pause / Step / Freeze
	 >> / Tune+
	 CH- / Page-
	 CH+ / Page+
	 Vol-
	 Vol+
	 Text / Goto
	 +  Shift + Pause / Step /
	 Sound / Title
	 D.Menu / Top
	 Menu / Home
	 +  Shift + 0

Original	Replacement

