






































Original	Replacement	Original	Replacement
	Power		Power
	Info		Rec
	Search		Red
	Sources		Green
	Up		Yellow
	Down		Blue
	Right		Vol+
	Left		Vol-
	OK		Mute
	←		Netflix
	Home		Windows
	≡		Rakuten Tv
	<<		CH+
	Play		CH-
	>>		Exit/Tv
	Stop		1
	Pause		2
			3





Original	Replacement	Original	Replacement
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Text		Text
	List/Tv Guide		Guide

