











































































Original		Replacement		Original		Replacement	
	Tuner		Shift + 6		9		9
	Tape		Shift + 5		Mono/ST		Menu / Home
	TV		Shift + 1		0		0
	V-CD		Shift + 2		Volume-		Vol-
	CD		Shift + 3		Volume+		Vol+
	DCC		Shift + 8		Mute		Mute / Dimmer
	VCR1		Shift + 4		FR.Direct		D.Menu / Top
	VCR 2		Shift + 7		Preset-		I<< / Preset-
	1		1		Preset+		>>I / Preset+
	2		2		Sleep		Sleep / Timer
	3		3		Display		Display / Media
	Standby		Power		Tuning-		<< / Tune-
	4		4		Tuning+		>> / Tune+
	5		5		Vol TV-		Shift + Vol-
	6		6		Vol TV+		Shift + Vol+
	7		7		Center Mode		OK
	8		8		Center Up		Up











































































Original		Replacement		Original		Replacement	
	Tuner		Shift + 6		8		8
	Tape		Shift + 5		9		9
	TV		Shift + 1		Disc Down		CH- / Page-
	V-CD		Shift + 2		0		0
	CD		Shift + 3		Volume-		Vol-
	DCC		Shift + 8		Volume+		Vol+
	VCR 1		Shift + 4		Mute		Mute / Dimmer
	VCR 2		Shift + 7		Play		Play / Slow
	1		1		I<		I<< / Preset-
	2		2		>I		>>I / Preset+
	3		3		Sleep		Sleep / Timer
	Standby		Power		Stop		Stop / Hold
	4		4		Display		Display / Media
	5		5		<<		<< / Tune-
	6		6		Pause		Pause / Step / Freeze
	Disc Up		CH+ / Page+		>>		>> / Tune+
	7		7		Center Mode		OK






























Original		Replacement		Original		Replacement	
	Tuner		Shift + 6		8		8
	Tape		Shift + 5		9		9
	TV		Shift + 1		Disc Down		CH- / Page-
	V-CD		Shift + 2		0		0
	CD		Shift + 3		Volume-		Vol-
	DCC		Shift + 8		Volume+		Vol+
	VCR 1		Shift + 4		Mute		Mute / Dimmer
	VCR 2		Shift + 7		Play		Play / Slow
	1		1		I<		I<< / Preset-
	2		2		>I		>>I / Preset+
	3		3		Sleep		Sleep / Timer
	Standby		Power		Stop		Stop / Hold
	4		4		Display		Display / Media
	5		5		<<		<< / Tune-
	6		6		Pause		Pause / Step / Freeze
	Disc Up		CH+ / Page+		>>		>> / Tune+
	7		7		Center Mode		OK







Original		Replacement		Original		Replacement	
	Tuner		Shift + 6		9		9
	Tape		Shift + 5		-/--		Guide / EPG / -/--
	TV		Shift + 1		0		0
	V-CD		Shift + 2		TXT		Text / Goto
	CD		Shift + 3		Rcvr Volume-		Shift + Vol-
	DCC		Shift + 8		Rcvr Volume+		Shift + Vol+
	VCR1		Shift + 4		Rcvr Mute		Shift + Mute / Dimmer
	VCR 2		Shift + 7		TV Mute		Mute / Dimmer
	1		1		Enlarge		Zoom / Size
	2		2		CH Down		CH- / Page-
	3		3		CH Up		CH+ / Page+
	Standby		Power		Sleep		Sleep / Timer
	4		4		Hold		Stop / Hold
	5		5		Display		Display / Media
	6		6		Page-		Shift + CH- /
	7		7		Cancel		Exit / Cancel / Clear
	8		8		Page+		Shift + CH+ / Page+



