





































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 P.Mode	 Picture / Format
 S.Mode	 Sound / Title
 Sleep	 Sleep / Timer
 Audio	 Audio / Lang I/II
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Freeze	 Pause / Step / Freeze
 0	 0

Original	Replacement
 Recall	 Back / Return
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Menu	 Menu / Home
 Up	 Up
 Source	 AV / Input / RDS
 Left	 Left
 OK / Enter	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 CH+	 CH+ / Page+
 Home	 Shift + Menu /
 Vol+	 Vol+





Original	Replacement
CH-	CH- / Page-
Mouse	Smart / List
Vol-	Vol-
<< / Text	<< / Tune-
>> / Text	Text / Goto
>> / Hold	Shift + Stop /
>> / Hold	>> / Tune+
l<< / Mix	l<< / Preset-
l<< / Mix	Shift + Text /
>>l / Reveal	>>l / Preset+
Play/Pause / Index	Play / Slow
Stop / Size	Stop / Hold
Stop / Size	Zoom / Size
FAV	Fav / Marker / PC
Aspect	Shift + Picture / Format
File	Display / Media
Delete	Eject / Surround

Original	Replacement
Zoom-	Shift + Down
Zoom+	Shift + Up
EPG	Guide / EPG / -/-
DTV / Radio	TV/Radio /
Rec	Rec / Rec Mode
Subtitle	Subtitle / EQ

