



















































	Original	Replacement		Original	Replacement
	Power		Power		Pause
	Function		Smart		Stop
	1		1		>>
	2		2		<<
	3		3		Album Up
	4		4		Album Down
	5		5		Enter
	6		6		Sleep
	7		7		Repeat
	8		8		Play Mode
	9		9		Clock Timer Set
	0/10		0		Clock Timer
	+10		Guide		Clear
	Disc Skip		Blue		Vol+
	Preset >>I		>>I		Vol-
	I<< Preset		I<<		Edit
	Play/<>		Play		Band
					Green



