






























Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info / Angle
	[=]		Text / Goto
	YouTube		Shift + Yellow / YouTube /
	Netflix		Shift + Red / Netflix /
	Disney Plus		Shift + Green / APP /
	prime video		Shift + Blue / Prime Video / Random
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Guide		Guide / EPG / -/-
	Rec List		Smart / List
	Source		AV / Input / RDS
	*		Menu / Home
	Micro		Display / Media
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		OK
	Back		Back / Return
	TV		TV/Radio /
	Home		Shift + Menu / Home





	Original	Replacement	Original	Replacement
	