























































Original	Replacement
	Power
	CD Direct 1
	CD Direct 2
	CD Direct 3
	Repeat
	Shuffle
	Program
	Sleep
	Timer
	Display
	Side (only)
	Pause
	Mute
	Vol-
	Vol+
	Play
	Stop

Original	Replacement
	I<
	>I
	<< / Tune-
	>> / Tune+
	Inc.Surr.
	Flat
	Loudness
	Bass-
	Bass+
	Treble-
	Treble+
	Balance L
	Balance R





















































Original	Replacement
	Repeat  Green / APP / Repeat
	Power 
	Shuffle  Blue / Prime Video / Random
	Program  TV/Radio /
	Sleep  Sleep / Timer
	Timer  Shift + Sleep / Timer
	Display  Display / Media
	Pause  Pause / Step / Freeze
	Mute  Mute / Dimmer
	Vol- 
	Vol+ 
	Play  Play / Slow
	Stop  Stop / Hold
	I<  I<< / Preset-
	>I  >>I / Preset+
	<<  << / Tune-
	>>  >> / Tune+

Original	Replacement
	Inc. Surr.  AV / Input / RDS
	Flat  Picture / Format
	Loudness  Zoom / Size
	Bass- 
	Bass+ 
	Treble-  CH- / Page-
	Treble+  CH+ / Page+
	Balance L 
	Balance R 





Original	Replacement
	 Power
	 +  Shift + Power
	 7
	 TV/Radio /
	 Sleep / Timer
	 +  Shift + Sleep / Timer
	 Display / Media
	 Mute / Dimmer
	 Vol-
	 Vol+
	 I<< / Preset-
	 >>I / Preset+
	 << / Tune-
	 >> / Tune+
	 AV / Input / RDS
	 Picture / Format
	 Sound / Title

Original	Replacement
	 Down
	 Up
	 CH- / Page-
	 CH+ / Page+
	 Left
	 Right

