







































































Original	Replacement	Original	Replacement
 Power	 Power	 8	 8
 Power Tv	 Shift + Power	 9	 9
 Tv/AV Tv	 Shift + AV / Input / RDS	 Vol+	 Vol+
 Vol+ Tv	 Shift + Vol+	 Cancel	 Exit / Cancel / Clear
 DVD	 Shift + 2	 0	 0
 FM	 TV/Radio /	 +10	 Guide / EPG / -/-
 EXT-IN	 AV / Input / RDS	 Vol-	 Vol-
 Vol- Tv	 Shift + Vol-	 I<< Skip	 I<< / Preset-
 1	 1	 Skip >>I	 >>I / Preset+
 2	 2	 << Slow/Search	 << / Tune-
 3	 3	 Slow/Search >>	 >> / Tune+
 Select >	 CH+ / Page+	 Stop	 Stop / Hold
 4	 4	 Pause	 Pause / Step / Freeze
 5	 5	 Play	 Play / Slow
 6	 6	 Quick OSD	 Red / Netflix / Search
 Select <	 CH- / Page-	 [I] VS	 Green / APP / Repeat
 7	 7	 One Touch Play	 Fav / Marker / PC



