































































































Original	Replacement
	 Power
	 Mute / Dimmer
	 Play / Slow
	 Pause / Step / Freeze
	 Stop / Hold
	 Rec / Rec Mode
	 << / Tune-
	 >> / Tune+
	 Subtitle / EQ
	 Eject / Surround
	 Picture / Format
	 Zoom / Size
	 TV/Radio /
	 Setup / OPT /
	 Text / Goto
	 AV / Input / RDS
	 Menu / Home

Original	Replacement
	 Up
	 Info / Angle
	 Left
	 OK
	 Right
	 Exit / Cancel / Clear
	 Down
	 Back / Return
	 Vol+
	 Smart / List
	 CH+ / Page+
	 Vol-
	 CH- / Page-
	 1
	 2
	 3
	 4









































































Original		Replacement		Original		Replacement	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	Guide		Guide / EPG / -/--				
	0		0				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				
	List		Shift + Smart / List				





























Original	Replacement
	 Power
	 Mute / Dimmer
	 Play / Slow
	 Pause / Step / Freeze
	 Stop / Hold
	 Rec / Rec Mode
	 << / Tune-
	 >> / Tune+
	 Subtitle / EQ
	 Eject / Surround
	 Picture / Format
	 Zoom / Size
	 TV/Radio /
	 Setup / OPT /
	 Text / Goto
	 AV / Input / RDS
	 Menu / Home

Original	Replacement
	 Up
	 Info / Angle
	 Left
	 OK
	 Right
	 Exit / Cancel / Clear
	 Down
	 Back / Return
	 Vol+
	 Smart / List
	 CH+ / Page+
	 Vol-
	 CH- / Page-
	 1
	 2
	 3
	 4





Original	Replacement	Original	Replacement
	5		5
	6		6
	7		7
	8		8
	9		9
	Guide		Guide / EPG / -/--
	0		0
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	List		Shift + Smart / List

Original	Replacement	Original	Replacement





Original	Replacement
	Power
	Mute / Dimmer
	Play / Slow
	Pause / Step / Freeze
	Stop / Hold
	Rec / Rec Mode
	<< / Tune-
	>> / Tune+
	Subtitle / EQ
	Eject / Surround
	Picture / Format
	Zoom / Size
	TV/Radio /
	Setup / OPT /
	Text / Goto
	AV / Input / RDS
	Menu / Home

Original	Replacement
	Up
	Info / Angle
	Left
	OK
	Right
	Exit / Cancel / Clear
	Down
	Back / Return
	Vol+
	Smart / List
	CH+ / Page+
	Vol-
	CH- / Page-
	1
	2
	3
	4



