




































Original	Replacement
 Standby	 Power
 Mute	 Mute / Dimmer
 EPG	 Guide / EPG / -/--
 Info	 Info / Angle
 TTX	 Text / Goto
 Audio	 Audio / Lang I/II
 DTV/VCR	 Smart / List
 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home
 UP	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 Exit	 Exit / Cancel / Clear

Original	Replacement
 Vol-	 Vol-
 Vol+	 Vol+
 Favourite	 Fav / Marker / PC
 Tv/Radio	 TV/Radio /
 1	 1
 2	 2
 3	 3
 Recall	 Back / Return
 4	 4
 5	 5
 6	 6
 Goto	 Shift + Text /
 7	 7
 8	 8
 9	 9
 0	 0
 <<	 << / Tune-





Original	Replacement
 FWD >>	 TUNE+ >> / Tune+
 PREV I<<	 PRESET- I<< / Preset-
 NEXT >>	 PRESET+ >> / Preset+
 PLAY Play	 SLOW Play / Slow
 PAUSE Pause	 STEP-FREEZE Pause / Step / Freeze
 STOP Stop	 HOLD Stop / Hold
 REPEAT Repeat	 SHIFT + APP + REPEAT Shift + Green / APP / REPEAT
 Red	 NETFLIX SEARCH Red / Netflix / Search
 Green	 APP REPEAT Green / APP / Repeat
 Yellow	 YouTube REPEAT A-B Yellow / YouTube / Repeat
 Blue	 Prime Video RANDOM Blue / Prime Video / Random

Original	Replacement

