




































































Original		Replacement		Original		Replacement	
	Standby		Power		Clear		Exit
	Open / Close		Eject		Setup		Options
	Mute		Mute		Search		TV/R
	OSD		Smart		Up		Up
	Step		Shift + Pause		Right		Right
	Recover		Media		Down		Down
	1		1		Left		Left
	2		2		Enter		Ok
	3		3		Subtitle		Subt
	4		4		Audio		Dual
	5		5		Play		Play
	6		6		Pause		Pause
	7		7		Stop		Stop
	8		8		I<<		I<<
	9		9		>>I		>>I
	0		0		<<		<<
	+10		Guide		>>		>>



