








































































Original	Replacement	Original	Replacement
 On	 Power	 Left	 Left
 Off	 +  Shift + Power	 1	 1
 Vol+	 Vol +	 2	 2
 Vol-	 Vol -	 3	 3
 Mute	 Mute	 4	 4
 Test	 Smart	 5	 5
 Night	 Exit	 6	 6
 [=]	 Text	 7	 7
 Sleep	 Sleep	 8	 8
 Surr.	 Dual	 9	 9
 SPKR/Menu	 Menu	 0	 0
 Delay/Normal	 Info	 Tun-M/[≡+]	 Guide
 CH./[≡?]	 TV/R	 Mem/[≡◇]	 Pre Ch
 Digital/[≡X]	 Media	 Tuning ▲	 Ch +
 Up	 Up	 Tuning ▼	 Ch -
 Down	 Down	 Direct/Green	 Green
 Right	 Right	 Clear/Yellow	 Yellow









































































Original	Replacement
 Preset ▲	 Shift + Ch +
 Preset ▼	 Shift + Ch -
 OSD	 Back
 RDS/D.Skip	 Options
 Set	 Ok
 Red	 Red
 Blue	 Blue
 DVD	 Shift + 2
 AVR	 Shift + 1
 CD	 Shift + 3
 Tape	 Shift + 4
 VID1/VCR	 Shift + 5
 VID2/TV	 Shift + 6
 VID3/CBL/SAT	 Shift + 7
 VID4	 Shift + 8
 AM/FM	 Shift + 9
 6/8 CH	 Shift + Guide

Original	Replacement
 > DVD	 Play
 Logic 7	 Shift + Pre Ch
 Stereo	 Shift + Blue
 DTS Neo 6	 Shift + Yellow
 DTS Surr.	 Shift + Green
 Dolby	 Shift + Red
 << DVD	 <<
 >> DVD	 >>
 Stop DVD	 Stop
 Pause DVD	 Pause
 I<</Skip Down	 I<<
 Skip Up/>>I	 >>I





Original	Replacement	Original	Replacement
 Power On	 Power	 3	 3
 Power Off	 Shift + Power	 4	 4
 Night	 Exit	 5	 5
 [≡]	 Text	 6	 6
 Vol+	 Vol +	 7	 7
 Vol-	 Vol -	 8	 8
 SPKR/Menu	 Menu	 9	 9
 CH./[≡?]	 TV/R	 0	 0
 Digital/[≡X]	 Media	 Tun-M/[≡+]	 Guide
 Delay/Normal	 Info	 Mem/[≡◇]	 Pre Ch
 Up	 Up	 Direct	 Smart
 Down	 Down	 Clear	 Shift + Exit
 Right	 Right	 Preset ▲	 Ch +
 Left	 Left	 Preset ▼	 Ch -
 Set	 Ok	 RDS/D.Skip	 Options
 1	 1	 >>	 >>
 2	 2	 <<	 <<





Original		Replacement		Original		Replacement	
	Power On		Power		Preset ▲/Blue		Ch +
	Power Off		Shift + Power		RDS/D.Skip		Options
	SPKR/Menu		Menu		>>		>>
	Delay/Normal		Info		<<		<<
	1		1		Play		Play
	2		2		Stop		Stop
	3		3		Pause		Pause
	4		4		>>		>>
	5		5		<<		<<
	6		6		Power (On /Off)		Media
	7		7		PR+ VCR		Shift + Ch +
	8		8		PR- VCR		Ch -
	9		9		Vol+ VCR		Vol +
	0		0		Vol- VCR		Vol -
	Tun-M/[≡+]		Guide		1 VCR		Shift + 1
	Mem/[≡◆]		Pre Ch		2 VCR		Shift + 2
	Direct		Smart		3 VCR		Shift + 3



