




















































Original	Replacement
 Power	 Power
 S.Mode	 Sound / Title
 MTS	 Text / Goto
 P.Mode	 Picture / Format
 Caption	 Subtitle / EQ
 Sleep	 Sleep / Timer
 P.Size	 Zoom / Size
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 Jump	 Smart / List
 .	 Display / Media
 Mute	 Mute / Dimmer
 Input	 AV / Input / RDS
 Vol+	 Vol+
 Vol-	 Vol-
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 Guide	 Guide / EPG / -/--
 Exit	 Exit / Cancel / Clear
 Up	 Up
 Down	 Down
 Down	 Shift + Down
 Left	 Left
 OK	 OK
 Info	 Info / Angle
 Menu	 Menu / Home





Original	Replacement
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Shift + Smart / List
	 Fav / Marker / PC
	 Shift + Sleep / Timer
	 Pause / Step / Freeze

Original	Replacement

