







































































Original	Replacement	Original	Replacement
 PWR	 Power	 Yellow/FAV	 Yellow / YouTube / Repeat
 Tv/Rad	 TV/Radio /	 Blue/A-Z	 Blue / Prime Video / Random
 Text	 Text / Goto	 Menu	 Menu / Home
 1	 1	 EPG	 Guide / EPG / -/-
 2	 2	 Info	 Info / Angle
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 OK
 8	 8	 Vol+	 Vol+
 9	 9	 Vol-	 Vol-
 0	 0	 Exit	 Exit / Cancel / Clear
 Back	 Back / Return	 Page+	 CH+ / Page+
 Mute	 Mute / Dimmer	 Page-	 CH- / Page-
 Red/Opt	 Red / Netflix / Search	 Pause	 Pause / Step / Freeze
 Green/AV+	 Green / APP / Repeat	 Play	 Play / Slow

Original	Replacement	Original	Replacement
 PWR	 DIMMER MUTE	 SHIFT	
 TV	 DVD	 SAT	 AUX
 SLOW	 STEP - FREEZE	 HOLD	 REC MODE
 TUNE-	 TUNE+	 PRESET-	 PRESET+
 TITLE	 LANG UII	 EQ	 SURROUND
 SOUND	 AUDIO	 SUBTITLE	 PROGRAM
 FORMAT	 ZOOM	 SLEEP	 TV RADIO
 TOP MENU	 OPT-TOOLS	 GOTO	 RDS
 D.MENU	 SETUP	 TEXT	 AV INPUT
 HOME	 ANGLE	 MENU	 INFO
 OK	 OK	 RETURN	 BACK
 CLEAR	 EXIT	 CANCEL	 LIST
 VOL+	 SMART	 MEDIA	 CH PAGE
 VOL-	 DISPLAY	 TV	 DVD
 1	 TAPE	 CD - STB	
 2	 TUNER	 VIDEO	
 3	 AUX - HDD	 USB	
 4	 BLUETOOTH	 HDMI - SAT	
 5	 PC	 GUIDE EPG	
 6	 FAV MARKER	 NETFLIX	 APP
7	SEARCH	REPEAT	REPEAT A-B
8	REPEAT	RANDOM	
9			
0			
MUTE			
STB			
			
www.mandis.tv			





Original	Replacement
<<	<< / Tune-
Stop	Stop / Hold
>>	>> / Tune+
Rec	Rec / Rec Mode
Slow	Shift + Play /
List	Smart / List
A-B	D.Menu / Top
Mark	Fav / Marker / PC
Jump	Subtitle / EQ
PIP	Zoom / Size
Swap	Setup / OPT /
Move	Display / Media
Sleep	Sleep / Timer

Original	Replacement

