





































































Original		Replacement		Original		Replacement	
	Power		Power		3 Tuner		3
	Sleep		Sleep / Timer		4 Tuner		4
	Phono		Red / Netflix / Search		5 Tuner		5
	Video		Blue / Prime Video / Random		6 Tuner		6
	Tape		Green / APP / Repeat		7 Tuner		7
	Tuner		TV/Radio /		8 Tuner		8
	CD		Yellow / YouTube / Repeat		9 Tuner		9
	Volume+		Vol+		10 Tuner		0
	Volume-		Vol-		Shift		Smart / List
	Disc Skip		Zoom / Size		1 CD		Shift + 1
	Play CD		Play / Slow		2 CD		Shift + 2
	Pause CD		Pause / Step / Freeze		3 CD		Shift + 3
	Stop CD		Stop / Hold		4 CD		Shift + 4
	I<< CD		I<< / Preset-		5 CD		Shift + 5
	>>I CD		>>I / Preset+		6 CD		Shift + 6
	1 Tuner		1		7 CD		Shift + 7
	2 Tuner		2		8 CD		Shift + 8



