





Original	Replacement
 Power	 Power
 Info	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / Zoom	 0
 0 / Zoom	 Eject
 Audio	 Dual
 Mute	 Mute
 Recall	 Back
 FAV	 Pre Ch

Original	Replacement
 Up / CH+	 Up
 Up / CH+	 Ch +
 Down / CH-	 Down
 Down / CH-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Menu	 Menu
 Exit	 Exit
 Blue / Pause	 Blue
 Blue / Pause	 Pause
 Red / Text	 Red
 Red / Text	 Text
 Multivideo	 Smart
 Yellow / Subtitle	 Yellow





Original	Replacement	Original	Replacement
 Yellow / Subtitle	 Subt		
 TV / AV	 AV		
 Green / P/N	 Green		
 SAT	 Media		
 TV / Radio	 TV/R		
 EPG	 Guide		





Original	Replacement	Original	Replacement
	Power		Power
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	TV/SAT		AV
	TV/Radio		TV/R
	Zoom		Eject
	List		List
	Audio		Dual
	EPG		Guide
	Timer		Shift + AV
	Text		Text
	Exit		Exit
	Menu		Menu
	M/P		Media
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	P+		>>
	P-		<<
	Recall		Pre Ch
	FAV		Shift + Pre Ch
	1		1
	2		2
	3		3
	4		4





	Original	Replacement	Original	Replacement
	5	5		
	6	6		
	7	7		
	8	8		
	9	9		
	0	0		
	Info	Info		
	Pause	Pause		

