
















































































Original	Replacement	Original	Replacement
 Power Receiver	 Power	 Audio 1	 1
 Sleep	 Sleep	 Audio 2	 2
 Vol+	 Vol +	 Audio 3	 3
 Vol-	 Vol -	 Audio 4	 4
 Mute	 Mute	 Audio 5	 5
 Return	 Back	 Audio 6	 6
 Enter	 Ok	 HDMI 1	 7
 Up	 Up	 HDMI 2	 8
 Down	 Down	 HDMI 3	 9
 Right	 Right	 Tuner Tuner	 Guide
 Left	 Left	 Memory Tuner	 Pre Ch
 Setup	 Menu	 Preset Up Tuner	 Ch +
 Option	 Options	 Preset Down	 Ch -
 BD/DVD	 Red	 Tuning Up	 >>
 TV	 Green	 Tuning Down	 <<
 CD	 Yellow	 Info	 Info
 Radio	 Blue	 Movie Sound	 Subt





Original	Replacement	Original	Replacement
 Music Sound	 Dual		
 Stereo/Enhancer Sound	 Format		
 Straight Sound	 AV		
 Sur. Decode	 3D		

