







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV		TV/R
	Recall		Pre Ch
	Mute		Mute
	Internet		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Q.Menu		D. Menu
	Back		Back
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	i/Info		Info
	Music/Photo/Phot		Options
	Guide		Guide
	[≡]/Text		Text
	*/O		Format





Original		Sustituto		Original		Sustituto	
	* / Q		3D				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	[≡]..		Subt				
	Rec		Rec				
	[-o-]		Eject				
	Play		Play				
	Stop		Stop				
	Pause		Pause				
	<<		<<				
	>>		>>				

