



Original	Sustituto
 Power	 Power
 Mute	 Mute
 HDMI	 AV
 FAV	 Shift + Pre Ch
 Tv/Radio	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Media	 Media
 LIB	 Smart

Original	Sustituto
 P:P	 Pre Ch
 EPG	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Info	 Info
 Exit	 Exit
 Menu	 Menu
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Rec	 Rec
 Play	 Play





Original	Sustituto	Original	Sustituto
 Stop	 Stop		
 <<	 <<		
 Pause	 Pause		
 >>	 >>		
 Text	 Text		
 Subt.	 Subt		
 Audio	 Dual		
 Opt.	 Options		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

