





































Original	Sustituto	Original	Sustituto
	Power		Power
	Tv/SAT		Smart
	Mute		Mute
	TV/R		TV/R
	Goto		Options
	Audio		Dual
	Aspect		3D
	Info		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

Original	Sustituto	Original	Sustituto
	0		0
	P+		Ch +
	P-		Ch -
	Recall		Back
	DEV		Media
	Up/CH+		Up
	Down/CH-		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Menu		Menu
	EPG		Guide
	FAV		Pre Ch
	Exit		Exit
	TTX		Text



