













































Original	Sustituto
 Standby/On	 Power
 1/5Beam	 1
 2/ST+3Beam	 2
 3/3Beam	 3
 4/Stereo	 4
 5/Target	 5
 6	 6
 7/Music	 7
 8/Movie	 8
 9/Vol Mode	 9
 0/Sports	 0
 +10/Off	 Guide / EPG / -/--
 Surround	 Eject / Surround
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left

Original	Sustituto
 AUX	 Smart / List
 Enter	 OK
 Menu	 Menu / Home
 Return	 Back / Return
 Test	 Text / Goto
 CH Level	 Info / Angle
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 (o)	 Sound / Title
 Input Mode	 AV / Input / RDS
 Sleep	 Sleep / Timer
 Power AUX	 Shift + Power
 1 AUX	 Shift + 1
 2 AUX	 Shift + 2
 3 AUX	 Shift + 3
 4 AUX	 Shift + 4





Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide / EPG / -/--
 Menu	 Menu / Home
 Return	 Back / Return
 Play	 Play / Slow
 <<	 << / Tune-
 >>	 >> / Tune+

Original	Sustituto
 Stop	 Stop / Hold
 Pause	 Pause / Step / Freeze
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 STB	 Shift + 3



