







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 [i+]/[?]	 DISPLAY INFO Info
 Source	 TIMER AV AV	 RETURN	 RETURN BACK Back
 [+]	 ECO 3D 3D	 ZOOM	 ZOOM Eject
 I<<	 I<<	 MENU	 TOP MENU MENU Menu
 >>I	 >>I	 Up	 Up
 <<	 <<	 Down	 Down
 >>	 >>	 Right	 Right
 Stop	 Stop	 Left	 Left
 Play	 PLAY MODE Play	 OK	 OK Ok
 Pause	 Pause	 1	 1
 Red	 A Red	 2	 2
 Green	 B Green	 3	 3
 Yellow	 C Yellow	 4	 4
 Blue	 D Blue	 5	 5
 REPEAT Repeat	 SHIFT + REPEAT TEXT Shift + Text	 6	 6
 AUDIO Audio	 SOUND DUAL Dual	 7	 7
 GUIDE Guide	 GUIDE Guide	 8	 8





	Original	Sustituto		Original	Sustituto
	9	9			
	0	0			
	FAV	+  Shift + Pre Ch			
	[≡]	Text			
	[...]	Subt			
	Vol+	Vol +			
	Vol-	Vol -			
	Mute	Mute			
	Prog+	Ch +			
	Prog-	Ch -			
	Recall	Pre Ch			

