









Original	Sustituto	Original	Sustituto
 POWER	 Power	 INFO	 Info
 MUTE	 Mute	 TV/RADIO	 TV/R
 1	 1	 CH+	 Ch +
 2	 2	 CH-	 Ch -
 3	 3	 LCD MENU	 Menu
 4	 4	 DVB MENU	 D. Menu
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 Enter	 Ok
 0	 0	 INPUT	 AV
 -/-	 -/- Guide	 PMODE	 Shift + Format
 Recall	 Back	 SMODE	 Dual
 VOL+	 Vol +	 SLEEP	 Sleep
 VOL-	 Vol -	 LIST	 List
 NICAM	 Smart	 FAV	 Pre Ch





Original	Sustituto	Original	Sustituto
PAGE-	<<		
PAGE+	>>		
TEXT	Text		
HOLD	Options		
EXIT	Exit		
EPG	Shift + Guide		
INDEX	3D		
SUBTITLE	Subt		
SIZE	Format		
REVEAL	Media		
RED	Red		
GREEN/AUDIO	Green		
YELLOW/PAUSE	Yellow		
BLUE	Blue		

Original	Sustituto

