


































































Original	Sustituto
 Power DVD	 Power
 Direct Tv Rec	 TV/R
 Drive Select HDD	 Media
 Drive Select DVD	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 * Cancel	 Guide
 Input Select	 AV
 CH+	 Ch +

Original	Sustituto
 CH-	 Ch -
 ShowView	 Blue
 Manual Skip	 Subt
 Skip	 I<<
 Skip	 >>I
 Slow/Search	 <<
 Slow/Search	 >>
 Stop	 Stop
 Pause	 Pause
 Play/x1.3	 Play
 Direct Navigator/Top	 Menu
 Functions	 Options
 Sub Menu	 D. Menu
 Return	 Back
 Up	 Up
 Down	 Down
 Right /	 Right





Original	Sustituto
	Left
	Ok
	Sleep
	Info
	3D
	Format
	Shift + AV
	Exit
	Shift + Rec
	Rec
	Red
	Green
	Yellow
	Dual
	Shift + Power
	Eject
	Shift + Ch +

Original	Sustituto
	Shift + Ch -
	Vol +
	Vol -

