





































Original	Sustituto
 Standby / On	 Power
 Open/Close / Eject	 Eject
 Mute	 Mute
 Speaker	 Red
 Test	 Green
 Sound Mode	 Yellow
 Sound Mode	 Shift + Dual
 Sound Effect	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Sustituto
 0	 0
 Angle	 Format
 Zoom / ATR.	 Shift + Eject
 Repeat / Mode	 Text
 Step	 Pause
 Prog/Trk+	 Ch +
 Prog/Trk-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 DVD	 Shift + 1
 VCR	 Shift + 2
 FM/AM	 Shift + 3
 INPUT	 AV
 INPUT	 Shift + 4
 I<< / <<	 I<<
 Stop	 Stop
 Play/Pause	 Play



