




































Original	Sustituto		
	Power		Power
	Ambilight		Pre Ch
	Windows		Shift + Media
	Tv/Exit		Exit
	Rakuten Tv		TV/R
	Menu		Menu
	Netflix		Media
	Pair/Sources		AV
	Smart/Colors		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	←		Back
	→		Options
	Home		Shift + Smart

Original	Sustituto		
	<<		<<
	Play		Play
	>>		>>
	Stop		Stop
	Pause		Pause
	Rec		Rec
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Tv Guide		Guide
	CH+		Ch +
	CH-		Ch -
	1		1



