



Original	Sustituto
	Power
	Shift + Mute / Dimmer
	Mute / Dimmer
	Smart / List
	Shift + 2
	Shift + TV/Radio / Program
	Shift + 7
	TV/Radio /
	Eject / Surround
	Shift + 4
	Shift + Display / Media
	Up
	D.Menu / Top
	Setup / OPT /
	Left
	OK
	Right

Original	Sustituto
	Guide / EPG / -/--
	Text / Goto
	Down
	Exit / Cancel / Clear
	CH+ / Page+
	Vol+
	CH- / Page-
	Vol-
	Stop / Hold
	Pause / Step / Freeze
	Play / Slow
	I<< / Preset-
	>>I / Preset+
	Blue / Prime Video / Random
	Green / APP / Repeat
	1
	2



