
































Original	Sustituto
 Power On	 Power
 Standby	 Shift + Power
 Input	 AV
 Mute	 Mute
 Vol Up	 Shift + Right
 Vol Down	 Shift + Left
 Volume+	 Vol +
 Volume-	 Vol -
 T/V/CH Level	 Smart
 CH/Album Up	 Ch +
 CH/Album Down	 Ch -
 Up	 Up
 Down/Search	 Down
 Sel >	 Right
 < Sel	 Left
 Enter	 Ok
 Play	 Play

Original	Sustituto
 Stop	 Stop
 </Pause	 Pause
 >> /Preset+	 >>
 <</Preset-	 <<
 >>/Tune+	 >>
 <</Tune-	 <<
 Setup/Home	 Media
 Test/Disc Menu	 Menu
 Dimmer/Return	 Back
 Display	 Info
 RDM/Room2	 Exit
 Audio	 Options
 Surround/Play List >	 Green
 < Surround/Play List	 Red
 Stereo/Play M	 TV/R
 1 / Tuner	 1
 2 / CD	 2































































Original	Sustituto	Original	Sustituto
F.AUX 3	3 / F.Aux 3	3	3
TAPE 4	4 / Tape 4	4	4
BT IN 5	5 / BT In 5	5	5
VIDEO 1 6	6 / Video 1 6	6	6
VIDEO 2 7	7 / Video 2 7	7	7
VIDEO 3 8	8 / Video 3 8	8	8
9	9	9	9
0	0	0	0
+10	10	-/-- GUIDE	Guide
EXT.IN	Ext In	D	Blue
SLEEP DOCK.M	Sleep	PROG SLEEP	Sleep
AVR	AVR	SHIFT + 1	Shift + 1
RECALL DOCK	Dock	SHIFT + 2	Shift + 2
SELECT CD	CD	SHIFT + 3	Shift + 3
AUX	AUX	SHIFT + 4	Shift + 4
BD	BD	SHIFT + 5	Shift + 5
TV	TV	SHIFT + 6	Shift + 6

Original	Sustituto	Original	Sustituto
SAT	SAT	SHIFT + 7	Shift + 7
CBL	CBL	SHIFT + 8	Shift + 8





































Original	Sustituto	Original	Sustituto
 Power On	 Power	 Audio	 Dual
 Standby	 Shift + Power	 Subtitle	 Subt
 Up	 Up	 1	 1
 Down	 Down	 2	 2
 Right	 Right	 3	 3
 Left	 Left	 4	 4
 Enter	 Ok	 5	 5
 Setup/Home	 Media	 6	 6
 Test/Disc Menu	 Menu	 7	 7
 Play	 Play	 8	 8
 Stop	 Stop	 9	 9
 >>	 >>	 0	 0
 <<	 <<		
 I<<	 I<<		
 >>I	 >>I		
 Display	 Info		
 Dimmer/Return	 Back		





	Original	Sustituto	Original	Sustituto
	CD			Power
	Play			Play
	Stop			Stop
	Pause			Pause
	I<<			I<<
	>>I			>>I
	1			1
	2			2
	3			3
	4			4
	5			5
	6			6
	7			7
	8			8
	9			9
	0			0





Original	Sustituto
Power On	Power
Standby	Shift + Power
RDM/Room2	Exit
CH/Album Up	Ch +
CH/Album Down	Ch -
Play	Play
Pause	Pause
Stop	Stop
>>	>>
<<	<<
I<<	I<<
>>I	>>I
Test/Disc Menu	Menu
Display	Info
Enter	Ok
Up	Up
Down	Down

Original	Sustituto
Audio	Options
< Surround/Play List	Red
Surround/Play List >	Green
Stereo/Play M	TV/R
Sleep / Dock M.	Sleep

