







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Vol-	 Vol-
 TV	 TV/Radio /	 PR+	 CH+ / Page+
 1	 1	 PR-	 CH- / Page-
 2	 2	 CH-List	 Display / Media
 3	 3	 Menu	 Menu / Home
 4	 4	 FAV-CH	 Fav / Marker / PC
 5	 5	 Tools	 Setup / OPT /
 6	 6	 Info	 Info / Angle
 7	 7	 Return	 Shift + Back / Return
 8	 8	 Exit	 Exit / Cancel / Clear
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 Alarm	 Smart / List	 Left	 Left
 Pre-CH	 Back / Return	 Right	 Right
 Mute	 Mute / Dimmer	 Enter	 OK
 Source	 AV / Input / RDS	 Red	 Red / Netflix / Search
 Vol+	 Vol+	 Green	 Green / APP / Repeat





Original	Sustituto
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Text / Goto
	Picture / Format
	Zoom / Size
	Audio / Lang I/II
	Guide / EPG / -/--
	Subtitle / EQ
	<< / Tune-
	Pause / Step / Freeze
	>> / Tune+
	Rec / Rec Mode
	Play / Slow
	Stop / Hold

Original	Sustituto

