




















| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Tv/R |  TV/R |
|  Last |  Back |
|  Menu |  Menu |
|  Exit |  Exit |
|  CH+ |  Ch + |

| Original | Sustituto |
|--|--|
|  CH- |  Ch - |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  PG+ |  >>I |
|  PG- |  I<< |
|  Audio |  Dual |
|  Mode |  Media |
|  EPG |  Guide |
|  Favor |  Pre Ch |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |



