





































Original	Sustituto
 Standby	 Power
 Auto	 Smart / List
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--	 Shift + Guide / EPG / -/--
 0	 0
 Recall	 Back / Return
 Vol+	 Vol+
 Aspect	 Shift + Picture / Format

Original	Sustituto
 Audio	 Audio / Lang I/II
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Display	 Display / Media
 CH-	 CH- / Page-
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Input	 AV / Input / RDS
 P.Mode	 Picture / Format
 S.Mode	 Sound / Title
 Sleep	 Sleep / Timer
 FAV	 Fav / Marker / PC





Original	Sustituto
FAV-	SHIFT + CH PAGE - Shift + CH- /
FAV+	SHIFT + CH PAGE + Shift + CH+ /
EPG	GUIDE EPG Guide / EPG / -/--
TEXT	GOTO TEXT Text / Goto
HOLD	SHIFT + HOLD Shift + Stop /
TV/RADIO	PROGRAM TV/RADIO TV/Radio /
SUBTITLE	EQ SUBTITLE Subtitle / EQ
INDEX	ANGLE INFO Info / Angle
SIZE	SIZE ZOOM Zoom / Size
REVEAL	OPT-TOOLS SETUP Setup / OPT /
SUBPAGE	SURROUND Eject / Surround
MEDIA	SHIFT + MEDIA DISPLAY Shift + Display / Media
Play	SLOW Play / Slow
Pause	STEP-FREEZE Pause / Step / Freeze
<<	TUNE- << / Tune-
>>	TUNE+ >> / Tune+
Rec	REC MODE Rec / Rec Mode

Original	Sustituto
Stop	HOLD Stop / Hold
I<<	PRESET- I<< / Preset-
>>I	PRESET+ >>I / Preset+
Red	NETFLIX Red / Netflix / Search
Green	APP Green / APP / Repeat
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat
Blue	Prime Video RANDOM Blue / Prime Video / Random

