



Original	Sustituto
 Standby	 Power
 Source	 AV / Input / RDS
 Home	 Shift + Menu /
 e	 D.Menu / Top
 Mouse	 Info / Angle
 TV / Radio	 TV/Radio /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Display	 Display / Media
 0	 0

Original	Sustituto
 Recall	 Back / Return
 Recall	 Fav / Marker / PC
 Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 Down	 Down
 Stop	 Stop / Hold
 Vol +	 Vol+
 TXT	 Text / Goto
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Mute	 Mute / Dimmer





	Original	Sustituto
	CH -	 CH- / Page-
	Mix / Fav. List	 Subtitle / EQ
	Mix / Fav. List	 Smart / List
	Size / Subtitle	 Zoom / Size
	Cancel / Audio	 Audio / Lang I/II
	Refresh	 Guide / EPG / -->
	<< / Index	 << / Tune-
	>> / Hold	 >> / Tune+
	<< / Reveal	  << / Preset-
	>>  / Subpage	 >>  / Preset+
	Red	 Red / Netflix / Search
	Green	 Green / APP / Repeat
	Yellow	 Yellow / YouTube / Repeat
	Blue	 Blue / Prime Video / Random

	Original	Sustituto

