




































Original	Sustituto
 Power	 Power
 Timer	 Sleep / Timer
 Sub TV	 TV/Radio /
 Preview	 Smart / List
 Snap	 Display / Media
 Shut Down	 Setup / OPT /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ↑	 Guide / EPG / -/--

Original	Sustituto
 ←	 Left
 Mute	 Mute / Dimmer
 Stereo	 Audio / Lang I/II
 Source	 AV / Input / RDS
 Zoom	 Zoom / Size
 Min	 Back / Return
 Up	 Up
 Down	 Down
 Left	 Shift + Left
 Right	 Right
 Enter	 OK
 Timeshift	 Picture / Format
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode
 <<	 << / Tune-
 >>	 >> / Tune+
 Play	 Play / Slow



