





































Original	Sustituto
	 Power
	 Mute
	 AV
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Eject
	 Dual
	 Back
	 Subt

Original	Sustituto
	 Info
	 Menu
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Vol +
	 Vol -
	 >>I
	 I<<
	 Play
	 Pause
	 <<
	 >>
	 Stop
	 Media



