

































































































Original	Sustituto
 Power	 Power
 Sleep	 Sleep / Timer
 Screen	 Picture / Format
 Presets	 Setup / OPT /
 ↔	 TV/Radio /
 FAV	 Shift + Fav / Marker / PC
 Lang	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 TXT	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Sustituto
 9	 9
 EPG	 Guide / EPG / -/-
 0	 0
 Swap	 Fav / Marker / PC
	 D.Menu / Top
	 Smart / List
	 AV / Input / RDS
	 Menu / Home
	
	
 OK	 OK
	
	
 C	 Exit / Cancel / Clear
	 Display / Media
	 Shift + Red / Netflix /
	 Back / Return





Original	Sustituto
 CH+	 CH+ / Page+
 Info	 Info / Angle
 Vol+	 Vol+
 CH-	 CH- / Page-
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 Rec	 Rec / Rec Mode
 Pause	 Pause / Step / Freeze
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 Play	 Play / Slow
 Stop	 Stop / Hold
 >>	 >> / Tune+
 Red/↑/Zoom	 Red / Netflix / Search
 Red/↑/Zoom	 Zoom / Size
 Green/↓/Repeat	 Green / APP / Repeat

Original	Sustituto
 Yellow/Root	 Yellow / YouTube / Repeat
 Blue/Title	 Blue / Prime Video / Random

