






























































Original	Sustituto
	 Power
	 Pause / Step / Freeze
	 Rec / Rec Mode
	 Stop / Hold
	 Play / Slow
	 >> / Tune+
	 << / Tune-
	 Guide / EPG / -/--
	 Shift + 3
	 Smart / List
	 Menu / Home
	 Display / Media
	 Picture / Format
	 TV/Radio /
	 OK
	 Up
	 Down

Original	Sustituto
	 Right
	 Left
	 Info / Angle
	 Exit / Cancel / Clear
	 Back / Return
	 Shift + List / Smart / List
	 Setup / OPT /
	 Mute / Dimmer
	 Vol+
	 Vol-
	 CH+ / Page+
	 CH- / Page-
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 1





Original		Sustituto		Original		Sustituto	
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Subtitle		Subtitle / EQ				
	Text		Text / Goto				
	Source		AV / Input / RDS				

